


- 1 Assemble upright frame A to rear beam B starting at the top using bolts G to fix in place.
- 2 Fit middle rear beams C to upright frames A.
- **3** Fit base tray **D** into bottom of upright frames **A**.
- 4 Add top dividers **E**.

- **5** Add bottom dividers **F** (used only with product VR27).
- **6** Fix to floor with fixing **K**.

NB. All bolts **G** and **H** torque to 60 Nm

COMPONENTS





Vertirack, Component Check							
	VR15	VR15E	VR15D	VR27	VR27E	VR27BD	VR27D
Uprights 'A'	-	-	-	2	1	-	-
Uprights 'H'	2	1	-	-	-	-	-
Top Rear Beams 'B'	1	1	-	1	1	-	-
Middle Rear Beams 'C'	1	1	-	2	2	-	-
Base Tray 'D'	1	1	-	1	1	-	-
Top Dividers 'E'	3	3	1	3	3	-	1
Bottom Dividers 'F'	-	-	-	3	3	1	-
End Fame Nuts	12	6	-	16	8	-	-
& Bolts 'G'							
Divider Nuts & Bolts 'H'	6	6	-	9	9	-	-